


CONGRATULATIONS YOUR ELEPHANTOM AS ARRIVED!

All the parts on your ELEPHANTOM are SNAP-ON, so you can assemble and disassemble fast and easy. This way you can store your ELEPHANTOM in a tight storage space like a backpacks pocket, and have it ready fast when you need it.

The first times you SNAP-ON/SNAP-OFF the sections, the parts may offer more resistance to the snap assembly process, but they will ease in with time and usage.

1. STEP: IDENTIFY ALL THE PARTS of your ELEPHANTOM




2. STEP: RIGHT SIDE OF PARTS

Printed parts have a SMOOTH side and a TEXTURED side.

The FACE section and the TAIL section have to be assembled with the SMOOTH SIDES FACING INSIDE (facing each other). So TEXTURED sides of these parts face OUTSIDE. If you don't follow this rule, ELEPHANTOM will not embrace your drone in the right away.

3. STEP: FACE - SPINE - SKIN - TAIL ASSEMBLY



Grab the SPINE part horizontally with the backbone up, and press the snap-on zones with your index and thumb and force it thru the top opening on the SMOOTH side of the FACE part.

INSERT THE SKIN section OVER THE SPINE.


Same as what you did with the FACE section, now SNAP-ON the other end of the SPINE with the SMOOTH side TOP opening on the TAIL section.

ALWAYS use these inside pressure points, with your index and thumb, to SNAP-ON/SNAP-OFF the SPINE section.

4. STEP: TUSKS ASSEMBLY

Each TUSK uses a special slot-n-hook system so it is the weight of the phone/tablet that makes it lock tight down. If you slide them contrary to the weight, then will easily come off.

To snap them in place, insert the top hook tab on the TUSK in a CW 45° angle on the top slot on the FACE plate. While you push it in, rotate the TUSK CCW to its final position, aligning the bottom tab with the bottom slot on the FACE plate.



THAT IS IT!

Your ELEPHANTOM is now assembled and ready to make your Drone an even more versatile filming machine.

To disassemble your ELEPHANTOM just reverse all the steps.

Please visit the product page for more instructions and Videos on how to assemble/disassemble and USE your ELEPHANTOM.

Check it out at: <http://ELEPHANTOM.bymac.org>

CAUTIONS USING YOUR ELEPHANTOM

While using your ELEPHANTOM with your drone on ground shots, remember that because of your drone not having the propellers running it can get hotter than usual. Especially the wifi module inside it. To prevent overheating, we recommend not leaving your drone ON for long periods at a time. In our tests we normally interval a 15 min use, with a 5 min cool off period and never had a problem.

NOTICE

No real animals were harmed creating your ELEPHANTOM.

ELEPHANTOM and **ELEPHANTOM MAMMOTH** are a *byMaC Inventions* design and product. We do not have any relation to any brand of drones our products are compatible with.



“smart people do smart things”
<http://www.bymac.org>